

# CHEAT SHEET

## Processes & Abbreviations

Processes	Description
Fluorination	Process of treating HDPE bottles with fluorine gas to improve their resistance to various chemicals.
Pad printing	Bottle printing method used when conventional screen printing isn't possible due to the bottle design.
Screen printing	Method of printing direct onto bottles

Abbreviations	Description
CRC	Child Resistant Closure
IHS	Induction Heat Seal
TE	Tamper Evident - a device that shows when a closure has been removed from a bottle, various forms available.
TWD	Tactile Warning Device - a triangle moulded into a bottle to assist blind persons in identifying hazardous products.
EPE	Expanded polyethylene – a material used in wads for closures.